

## **Maintenance for Chromatile Solid**

The only way to protect your carpet investment is to ensure regular maintenance is carried out, and a suitable Barrier Matting system is incorporated into the design at every entrance to the building.

Barrier matting installed and used correctly greatly reduces the transferral of external contaminants being introduced in to the building, thus reducing potential soiling to your floor covering. We recommend Object Carpet Step-in which is a heavy duty barrier matting that has been specifically developed and engineered to reduce the large amounts of dirt and debris carried into buildings by people traffic. Step-in can absorb up to 5 litres of water per m2.

Daily maintenance of your floor covering is required to maintain a good level of day one installation appearance retention. For best results use a brush vacuum cleaner with effective suction and brush action, bearing in mind that the vacuum head may be to be adjusted depending on the pile height and surface of floor covering. Particular attention should be paid to heavy traffic areas, such as reception, breakout/refreshment areas, corridors and walkways. Medium traffic areas such as meeting rooms should be vacuumed at least every other day. This is the only way to prevent premature pile crush in traffic lanes.

Spots and stain should be treated immediately and most can be removed with general attention dabbing with luke warm water and blot with absorbent cloth and then reported to be dealt with more effectively by the method preferred by the daily office cleaning company. Stains and spots should not be rubbed or twisted into the pile of the carpet.

### **Barrier Matting**

<http://Chroma.im/products/object/barrierMatting/barrierMatting.html>

### **Recommended Vacuum Cleaner – Sebo BS46 Twin Motor**

#### **Commercial Upright**

